



Tabella di conversione pollici in pollici decimali e mm

inch	dec. in	mm	inch	dec. in	mm	inch	dec. in	mm	inch	dec. in	mm
0	0	0	17/64	0.265625	6,7469	17/32	0.53125	13,4938	51/64	0.796875	20,2406
1/64	0.015625	0,3969	9/32	0.28125	7,1438	35/64	0.546875	13,8906	13/16	0.8125	20,6375
1/32	0.03125	0,7938	19/62	0.296875	7,5406	9/16	0.5625	14,2875	53/64	0.828125	21,0344
3/64	0.046875	1,1906	5/16	0.3125	7,9375	37/64	0.578125	14,6844	27/32	0.84375	21,4312
1/16	0.0625	1,5875	21/64	0.328125	8,3344	19/32	0.59375	15,0812	55/64	0.859375	21,8281
5/64	0.078125	1,9844	11/32	0.34375	8,7312	39/64	0.609375	15,4781	7/8	0.875	22,2250
3/32	0.09375	2,3812	23/64	0.359375	9,1281	5/8	0.625	15,8750	57/64	0.890625	22,6219
7/64	0.109375	2,7781	3/8	0.375	9,5250	41/64	0.640625	16,2719	29/32	0.90625	23,0188
1/8	0.125	3,1750	25/64	0.390625	9,9219	21/32	0.65625	16,6688	59/64	0.921875	23,4156
9/64	0.140625	3,5719	13/32	0.40625	10,3188	43/64	0.671875	17,0656	15/16	0.9375	23,8125
5/32	0.15625	3,9688	27/64	0.421875	10,7156	11/16	0.6875	17,4625	61/64	0.953125	24,2094
11/64	0.171875	4,3656	7/16	0.4375	11,1125	45/64	0.703125	17,8594	31/32	0.96875	24,6062
3/16	0.1875	4,7625	29/64	0.453125	11,5094	23/32	0.71875	18,2562	63/64	0.984375	25,0031
13/64	0.203125	5,1594	15/32	0.46875	11,9062	47/64	0.734375	18,6531	1	1	25,4
7/32	0.21875	5,5562	31/64	0.484375	12,3031	3/4	0.75	19,0500			
15/64	0.234375	5,9531	1/2	0.5	12,7000	49/64	0.765625	19,4469			
1/4	0.25	6,3500	33/64	0.515625	13,0969	25/32	0.78125	19,8438			

Indicazioni profili Torx®

Dimensione delle chiavi Torx® / Torx® Plus	
Maschio	
Grandezza	mm
T6	1,67
T7	1,99
T8	2,31
T9	2,50
T10	2,74
T15	3,27
T20	3,86
T25	4,43
T27	4,99
T30	5,52
T40	6,65
T45	7,82
T50	8,83
T55	11,22
T60	13,25
T70	15,49

Dimensione delle chiavi Torx®	
Femmina	
Grandezza	mm
E4	3,86
E5	4,75
E6	5,74
E7	6,22
E8	7,52
E10	9,42
E12	11,17
E14	12,90
E16	14,76
E18	16,70
E20	18,45
E24	22,16

CHIAVI